

MANUAL | USER GUIDE **BOARD**

READ THIS USER GUIDE CAREFULLY BEFORE USING YOUR BOARD



ASSUMPTION OF RISK

Use of the VAYU product and any of its components involves certain inherent risks, dangers, and hazards that can result in serious personal injury and death to both the user and to nonuser third parties. In using the VAYU product, you freely agree to assume and accept all known and un-

known risks of injury to you and to third parties while using this equipment. The risks inherent in this sport can be greatly reduced by abiding the warning guidelines listed in this owner manual and by using common sense.

RELEASES AND WAIVER OF CLAIMS

In consideration of your use of this product, you hereby agree to the following, to the fullest extent permitted by law:

To waive all claims that you have or may have in the future against VAYU Sports UG or any of its agents, resulting from use of this product and any of its components.

To release VAYU Sports UG or any of its agents from all liability for any loss, dama-

ge, injury or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of VAYU Sports UG or any of its agents, in the design or manufacture of this product.

BINDING EFFECT OF AGREEMENT

In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, associates and representatives.

ENTIRE AGREEMENT

In entering into this Agreement, you are not relying upon any oral or written represen-

tations other than what is set forth in this agreement and User's Guide.

WARNING & SAFETY PRECAUTIONS

Wing foiling can be a dangerous sport. Always use extreme caution when using this product. Misuse of this product can cause serious injury or death.

- Only use on unobstructed stretches of water.
- Only ride the Wing foil if you are a good swimmer, and you are wearing a life jacket.

- You are responsible for your own safety and the safety of others around you when using this product.
- You can hurt yourself through uncontrolled water take-offs caused by gusty conditions, and the danger of collisions with obstacles.



THE LISTED RISKS CANNOT BE COMPLETED

The basic rules for foil wing foiling comply with those of common sense and are valid

for all outdoor sports.

FITTING THE FOOTSTRAPS ONTO THE BOARD

If you are not sure which position you prefer, choose the central position as a first reference. Use the screws provided. Fasten the screw through the foot strap into the plastic insert of the board. Watch the angle of the screw to avoid damaging the board.

FITTING THE FOIL ONTO THE BOARD

STEP 1:

Place the board upside down on a surface that will not damage it.

STEP 2:

Place two T-nuts, assembled with two M8x30 screws (keep them as loose as possible), into the twin tracks. Slide them to the back

STEP 3:

Insert two M8x30 screws into two front holes of the top plate and assemble with

the T-nuts (keep them loose too)

STEP 4:

Slide the mast and top plate with the front nuts forward into the twin tracks. Slide the plate forward until you can slide the back screws into the rear slots of the top plate

STEP 5:

Place the top plate at the desired position along the twin tracks and fasten the four screws until they are tight

ADJUSTMENT

Place the foil in a central position as a first reference. If the foil is in a more forward position, the foil will rise sooner and higher.

In a more backward position, the foil will rise less.

MAINTANANCE

- Clean the board after every ride with clean water
- Protect the board with a VAYU boardbag from unnecessary sun and scratches
- Do not leave your board exposed to the sun on the beach for too long
- Check your Board for holes, coming from any damage. Damage must be fixed and sealed properly before further use



WARRANTY

- VAYU Warrants this product to be free of major defects in materials or workmanship to the original purchaser for a period of six months from the original date of purchase. This warranty is subject to the following limitations: The warranty is valid only when the product is used for foil wing foiling on water and does not cover products used in rental or teaching operations.
- VAYU will make the final warranty determination, which may require inspection and/or photos of the equipment, which clearly show the defect(s). If necessary, this information must be sent to the VAYU distributor in your country, postage prepaid.
- If a product is deemed to be defective by VAYU, the warranty covers the repair or replacement of the defective product only.
- VAYU will not be responsible for any costs, losses or damages incurred as a

- result of loss of use of this product. The warranty does not cover damage caused by misuse, abuse, neglect or normal wear and tear including but not limited to, rigging with other than VAYU components, damage due to excessive sun exposure, damage caused by improper handling or storage, damage caused by use in the waves or shore break and damage caused by anything other than defects in material and workmanship.
- This warranty expires if any unauthorized repair, change or modification has been made to any part of the equipment.
 The warranty for any repaired or replaced equipment is valid as of the date of the original purchase only. The original purchase receipt must accompany all warranty claims. The name of the retailer and date of purchase must be clear and legible. There are no warranties that extend beyond the warranty specified herein.

WARRANTY CLAIMS

Warranty claims must be processed and be issued and a return authorization must be issued prior to VAYU.



contact: support@vayu.world

GERMANY

Kiel

Koppelberg 4-6, 24159

SPAIN

San Sebastian

Avenida Navarra 50, 20013

USA

Portland

SE Ankeny 3463, 97214 US